



FIVE STAR
Foreign Trade


**PCP AIR RIFLES
USER MANUAL**





FIVE STAR
Foreign Trade

General Part Explanation





FIVE STAR
Foreign Trade

Demount And General Explanation (Visual)



SEPARATING THE BODY

The carbine stock (monoblock) side of your airgun has been balanced from the center of gravity, positioned not to be subject to pressure or impact and fixed with a single Allen head screw. You can remove easily with the help of 4 Allen.



TRIGGER ADJUSTMENT

You can adjust the trigger movement distance without disassembling the airgun but only through the below of the trigger guardrail (see picture 1) and adjust the hammer falling through the inner trigger set screw.



SAFETY

Safety 'F' position means ready to fire

Safety 'S' position means blocked to fire





FIVE STAR
Foreign Trade

Demount And General Explanation (Visual)

MAGAZINE PLACEMENT

The new generation mechanic magazine can be attached and removed from the right side. The magazine that has run out of pellet will not allow new charge



POWER ADJUSTMENT

The power regulating valve is adjusted only from the screw on the back of the body.



MONOMETER

Monometer might vary based on the Lord models.
(For balloon model and for cylinder models)





FILLING THE AIR TANK

The filling outlet is located at the tip of the air tube. Assemble the hose with the filling jack that is provided free of charge inside the box as a standard. If you hear the sound of air during the first filling, move the jack and enable the o rings to be air-proof. (if the leakage continues, o rings might be deformed)



SINGLE SHOT ASSISTANT

The single-shot kit is a part that can be attached and removed only from the right side. 4.5 mm (0.177) can be used with different sizes of kit while 5.5 mm (0.22) and 6.35 mm (0.25) can use the same kit.



BARREL INNER & OUTER O RING

Barrel tightness o rings are three in total and 2 of them are outside while 1 is inside. In case of deformation, please replace it with the spare O rings that are available inside the package.





FIVE STAR
Foreign Trade

Barrel Disassemble




With the help of a hand, loosen it counterclockwise



Remove the barrel clothing ring.



Loosen the allen that holds the barrel fixed. (Hex 4)



Loosen the second allen that holds the barrel steady. (Hex 4)






FIVE STAR
Foreign Trade

How To Fill The Magazine



Rotate the idle front cover in the direction of the arrow (clockwise).



Once the glass cover hits the last point, prevent the pushing force of the spring and switch the Pellet to the first bed.
Once the first pellet prevents the rotation of the inner turret, move the glass cover on the contrary direction and fill the turret.




FIVE STAR
Foreign Trade

Mechanism Part


DIAGRAM

MECHANICALLY INDEXED MAGAZINE



DIAGRAM

RECEIVER & BARREL
COMPONENTS





FIVE STAR
Foreign Trade

Mechanism Part

DIAGRAM


AIR TANK (CYLINDER TUBE)





DIAGRAM

AIR TANK (BALLOON TUBE)





FIVE STAR
Foreign Trade

Stock

STOCKS





FIVE STAR

Foreign Trade



+90 544 749 95 27



+90 546 669 75 27



info@fivestearms.net



www.fivestearms.net



Evsat Mahallesi Antalya Cad.
Raşit Toptaş No:31 İç Kapı No:302
Beyşehir/KONYA/TURKEY